



## 1. Introduction

This document provides operating, maintenance and installation instructions. This unit measures and displays the characteristics of single phase two wires(1p2w), three phase three wires(3p3w) and three phase four wires(3p4w) networks. The measuring parameters include voltage(V), frequency(Hz), current(A), power (kW/kVA/kVAr), import, export and total Energy(kWh/kVArh). The unit can also measure Maximum demand of current and power. This is measured over preset periods of up to 60 minutes.

This unit is a 1A or 5A current transformer operated and can be configured to work with a wide range of CTs. Built-in Pulse, Modbus, Ethernet or Mbus outputs. Configuration is password protected.

This unit can be powered by a separate auxiliary (AC or DC) supply. Alternatively it can be powered from the monitored supply by linking the voltage reference and neutral reference to terminals 5 and 6(Please refer to wiring diagram).

## 1.1 Unit Characteristics

Model table:

Model	Measurement	Outputs	Tarif fs
EMM.630MCT	Multi-parameters	Pulses & RS485	Single Tariff
EMM.630MCT-TCP	Multi-parameters	Ethernet TCP	Single Tariff
EMM.630MCT-DI	Multi-parameters	RS485	Single Tariff

## 2. Start Up Screens

	The first screen lights up all display segments and can be used as a display check.
	Software version information (This information is for reference only, in kind prevail.)
	The interface performs a self-test and indicates the result if the test passes.

\*After a short delay, the screen will display active energy measurements.

## 3. Measurements

The buttons operate as follows:

	Selects the Voltage and Current display screens. In Set-up Mode, this is the "Left" or "Back" button.
	Select the Frequency and Power factor display screens. In Set-up Mode, this is the "Up" button.
	Select the Power display screens. In Set-up Mode, this is the "Down" button.
	Select the Energy display screens. In Set-up mode, this is the "Enter" or "Right" button.

## 3.1 Voltage and Current

Each successive press of the button selects a new parameter:

	Phase to neutral voltages.
	Current on each phase.
	Neutral Current
	Phase to neutral voltage THD%.
	Current THD% for each phase.

## 3.2 Frequency and Power Factor and Demand

	Frequency and Power Factor (total).
	Power Factor of each phase.
	Maximum Current Demand.
	Maximum Power Demand.

## 3.3 Power

	Instantaneous Active Power in kW.
	Instantaneous Reactive Power in kVAr.
	Instantaneous Volt -Ampsin kVA.
	Total kW, kVAr, kVA.

## 3.4 Energy Measurements

	Total Active Energy in kWh.
	Total Reactive Energy in kVArh.
	Import Active Energy in kWh. *Not shown on 2 tariffs or 4 tariffs meter
	Export Active Energy in kWh. *Not shown on 2 tariffs or 4 tariffs meter
	Import Reactive Energy in kVArh. *Not shown on 2 tariffs or 4 tariffs meter
	Export Reactive Energy in kVArh. *Not shown on 2 tariffs or 4 tariffs meter

## 4 Set Up

To enter set-up mode, press the button for 3 seconds until the password screen appears.

	Setting up is password-protected. The user should enter the correct password(default '1000') before processing.
	If an incorrect password is entered, the display will show: PASS Err
	To exit setting-up mode, press  repeatedly until the measurement screen is restored.

### 4.1 Set-up Entry Methods

Some menu items, such as password and CT, require a four-digit number entry while others, such as supply system, require selection from a number of menu options.

## 4.1.1 Menu Option Selection

- 1.Use the and buttons to scroll through the different options of the set up menu.
- 2.Long press to confirm your selection.
- 3.If an item flashes, then it can be adjusted by the and buttons.
- 4.Having selected an option from the current layer, long press to confirm your selection.
- 5.Having completed a parameter setting, press to return to a higher menu level.
- You will be able to use the and buttons for further menu selection.
- 6.On completion of all setting-up, press repeatedly until the measurement screen is restored.

## 4.1.2 Number Entry Procedure

When setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:

- 1.The current digit to be set flashes and is set using the and buttons.
- 2.Long press to confirm each digit setting.
- 3.After setting the last digit, press to exit the number setting routine.

## 4.2 Communication

### 4.2.1 RS485/Mbus Primary Address



(The range is from 001 to 247 for Modbus and 001 to 250 for Mbus)

	From the Set-Up Menu,  and  buttons to select the address ID.
	Long press  button to enter the selection routine. The current setting will flash.
	Use  and  buttons to choose Modbus or Mbus primary address

Procedure, press button to confirm the setting and press button to return the main Set-Up Menu.

## 4.2.3 Baud Rate

Baud rate range for Modbus RTU: 2.4k, 4.8k, 9.6k, 19.2k, 38.4k.

	From the Set-Up Menu, use  and  buttons to select the baud rate option.
	Long press  to enter the selection routine. The current setting will flash.
	Use  and  buttons to choose baud rate 2.4k, 4.8k, 9.6k, 19.2k, 38.4k

Press to confirm the setting and press to return to the main Set-Up Menu.

## 4.2.4 Parity

	From the Set-Up Menu, use  and  buttons to select the parity option.
	Press  to enter the selection routine. The current setting will flash.
	Use  and  buttons to choose parity (EVEN/ODD/NONE(default)).

Press to confirm the setting and press to return to the main Set-Up Menu.

## 4.5.1 Pulse Rate

Use this to set the energy represented by each pulse. Rate can be set to 1 pulse per 0.01/0.1/1/10/100/1000kWh/kVArh.

	(It shows 1 impulse =10kWh/kVArh)
	From the Set-Up Menu, use  and  buttons to select the pulse rate option.
	Press  to enter the selection routine. The current setting will flash. 0.01/0.1/1/10/100/1000kWh/kVArh per pulse.

Use and buttons to choose pulse rate. Long press to confirm the setting and press to return to the main Set-Up Menu.




Use and buttons to choose stop bit(2 or 1)  
Note: Default is 1, and only when the parity is NONE that the stop bit can be changed to 2.

Long press to confirm the setting and press to return to the main Set-Up Menu.

## 4.3 CT

The CT option sets the secondary current (CT2 1A or 5A) of the current transformer (CT) that wires to the meter.



From the Set-Up Menu, use and buttons to select the CT option.



Secondary CT setting  
Press to enter the CT Secondary current selection routine: 5A/1A.



Set CT rate value  
Press to enter the CT rate setting screen. The range is from 0001 to 9999.


</div

#### 4.5.2 Pulse Duration

The energy monitored can be active or reactive and the pulse width can be set as 200,100 or 60ms.



(It shows pulse width of 200ms)




From the Set-Up Menu, use **M ↑** and **P ↓** buttons to select the pulse width option.

Press **E ↴** to enter the selection routine. The current setting will flash.

Use **M ↑** and **P ↓** buttons to choose pulse width. Long press **E ↴** to confirm the setting and press **W1** to return to the main Set-Up Menu.

#### 4.6 DIT Demand Integration Time

This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are:0,5,8,10,15,20,30,60 minutes.



From the Set-Up Menu, use **M ↑** and **P ↓** buttons to select the DIT option. The screen will show the currently selected integration time.


Press **E ↴** to enter the selection routine. The current time interval will flash.

Use **M ↑** and **P ↓** buttons to choose the selection. Long press **E ↴** to confirm the setting and press **W1** to return to the main Set-Up Menu.

#### 4.7 Backlit Set-up

The meter provides a function to set the backlit lasting time (0/5/10/30/60/120 minutes).

Option 0 means the backlit always on here.




Default:60  
If it is set as 5, the backlit will be off in 5 minutes.

use **M ↑** and **P ↓** buttons to choose the time.

Long press **E ↴** to confirm the setting and press **W1** to return to the main Set-Up Menu.

#### 4.8 Supply System

The unit has a default setting of three phase four wires (3P4W). Use this section to set the type of electrical system.



From the Set-Up Menu, use **M ↑** and **P ↓** buttons to select the system option. The screen will show the currently selected system type.


Long press **E ↴** to enter the selection routine. The current selection will flash.

use **M ↑** and **P ↓** buttons to select the required system option:1P2(W), 3P3(W), 3P4(W).

Press **E ↴** to confirm the selection. Press **W1** to exit the system selection routine and return to the menu.

#### 4.9 CLR

The meter provides a function to reset the maximum demand value of current and power.



From the Set-Up Menu, use **M ↑** and **P ↓** buttons to select the reset option.


Long press **E ↴** to enter the selection routine. The "MD" will flash.

Long press **E ↴** to confirm the setting and press **W1** to return to the main Set-Up Menu.


#### 4.10 Change Password



Use **M ↑** and **P ↓** to choose the change password option.



Press the **E ↴** to enter the change password routine. The new password screen will appear with the first digit flashing.



Use **M ↑** and **P ↓** to set the first digit and press **E ↴** to confirm your selection. The next digit will flash.

Repeat the procedure for the remaining three digits.



After setting the last digit, Press **E ↴** to confirm the selection.



Press **E ↴** to exit the number setting routine and return to the Set-Up Menu.

The unit provides two pulse outputs. Both pulse outputs are passive type.

Pulse output 1 is configurable. The pulse output can be set to generate pulses to represent total kWh or kVarh. The pulse constant can be set to generate 1 pulse per:




0.01 = 10 Wh/VArh  
0.1 = 100 Wh/VArh  
1 = 1 kWh/kVArh  
10 = 10 kWh/kVArh  
100 = 100 kWh/kVArh

1000=1000 kWh/kVArh  
Pulse width: 200/100(default)/60ms  
Pulse output 2 is non-configurable. It is fixed up with total kWh. The constant is 3200imp/kWh.

\*Not available on EMM.630MCT-TCP or EMM.630MCT-DI


#### 8. Wiring Diagram

##### Current and Voltage Inputs




##### Definitions of Other Terminals


###### EMM.630MCT



###### EMM.630MCT-DI



###### EMM.630MCT-TCP



#### 5. Specifications

##### 5.1 Voltage and Current

- Voltage AC(Un)
- Voltage Range
- Rated Current (Iref)
- Current Input
- Over Current Withstand
- Voltage Circuit
- Current Circuit
- Frequency

3x230/400V  
100-277V AC  
10-50A  
0.05-5(6)A, Max. 6A  
20lmax for 0.5S  
<2W/10VA  
<1VA  
50/60Hz

##### 5.2 Auxiliary Power Supply

- Operating range
- Current range
- Consumption

100-277V AC  
0.04A  
<10W

\*For billing operation: auxiliary power supply shall be permanently energized.

##### 5.3 Accuracy

- Voltage
- Current
- Frequency
- Power factor
- Active power (W)
- Reactive power (VAr)
- Apparent power (VA)
- Active energy (Wh)
- Reactive energy (VArh)
- Total harmonic distortion
- Response time to step input

0.5% of range maximum  
0.5% of nominal  
0.2% of mid-frequency  
1% of unity (0.01)  
±1% of range maximum  
±1% of range maximum  
±1% of range maximum  
Class 1 IEC 62053-21  
Class 2 IEC 62053-23  
1%up to 31st harmonic  
1s, typical, to >99% of final reading, at 50 Hz.

##### 5.4 Insulation

- AC voltage withstand
- Impulse voltage withstand

4KV for 1 minute  
6KV

##### 5.5 Environment

- Operating temperature
- Storage and transportation temperature
- Reference temperature
- Relative humidity
- Installation category
- Altitude
- Protective Class
- Location
- Warm up time
- Mechanical environment
- Electromagnetic environment
- Installation environment
- Degree of pollution

-40 to +70  
-40 to +80  
23 2  
0 to 95%, non-condensing  
CAT III  
Up to 2000m  
II  
Dry  
3s  
M1  
E2  
wall or cabinet  
2


##### 5.6 Mechanics

- DIN rail dimensions
- Mounting
- Ingress protection
- Material

72x94.5x65mm(WxH)  
per DIN43880  
DIN rail 35mm  
Front Panel IP51 (indoor)  
Self-extinguishing  
UL94 V-0

##### 5.7 Pulse Output

The meter is equipped with pulse output, which is fully isolated from the inside circuit. That generates pulses in proportion to the measured energy. The pulse output is polarity dependent, passive transistor output requiring an external voltage source for correct operation. For this external voltage source, the voltage shall be 5-27V DC, and the maximum input current shall be 27mA DC.



ATTENTION: Pulse output must be fed as shown in the wiring diagram on the left. Scrupulously respect polarities and the connection mode. Opto-coupler with potential-free SPST-NO Contact.

Contact range:5-27VDC  
Max. current Input:27mA DC

The unit provides two pulse outputs. Both pulse outputs are passive type.

Pulse output 1 is configurable. The pulse output can be set to generate pulses to represent total kWh or kVarh. The pulse constant can be set to generate 1 pulse per:

0.01 = 10 Wh/VArh  
0.1 = 100 Wh/VArh  
1 = 1 kWh/kVArh  
10 = 10 kWh/kVArh  
100 = 100 kWh/kVArh

1000=1000 kWh/kVArh  
Pulse width: 200/100(default)/60ms  
Pulse output 2 is non-configurable. It is fixed up with total kWh. The constant is 3200imp/kWh.

\*Not available on EMM.630MCT-TCP or EMM.630MCT-DI

#### 5.8 RS485 Modbus RTU

For Modbus RTU, the following RS485 communication parameters can be configured from the Set-up menu:  
Baud rate: 2400, 4800, 9600, 19200, 38400bps

Parity: NONE (default)/ODD/EVEN

Stop bits: 1 or 2

RS485 network address nnn – 3-digit number, 001 to 247

#### 5.9 Ethernet Modbus TCP

For Ethernet Modbus TCP, the following communication parameters can be configured from the Set-up Menu:

Modbus address range: 1-247

IP: 192.168.1.200(default)

Port: 502

MASK: 255.255.255.0

Gateway: 192.168.1.1

DHCP: Off(default)

DHCP: Off(default)